



15301880
Revision C
February 2025

Combination Assembly

1500 Series


Parts Information



Save These Instructions

ARO

Combination 1500 Series C382X1-XXX Exploded Diagram



(Dwg. 15321953)

Combination 1500 Series C382X1-XXX Diagram Parts List

Item	Part Description	Material	Part Number
1	Filter (See Part List 15301849)	---	F352XX-XXX
2	Regulator (See Part List 15301856)	---	R372X1-XXX
3	Lubricator (See Part List 15301864)	---	L362X1-XXX
*	Piggyback (See Part List 15301872)	---	P392XX-XXX
4	I-Bracket	Aluminum	104400
5	T-Bracket		
6	Bolt	Steel	
7	"O" Ring	Nitrile	

* Not illustrated.

Parts and Maintenance

When the life of the tool has expired, it is recommended that the tool be disassembled, degreased and parts be separated by material so that they can be recycled.

Tool repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **ARO** Office or Distributor.

Related Documentation

For additional information refer to:

Safety Information Manual 15301765.

Product Information Manual 15301773.

Maintenance Information Manual 15301781.

Manuals can be downloaded from arozone.com.



Part No: 100400-65

arozone.com

© 2025 **ARO**

ARO

